

ELECTRIC SERVICE SCHEDULE NO. 136 – Continued

8. For customer-generators generation systems of 10 kilowatts or less that are inverter-based, a disconnect switch is not required. For all other generation systems, the customer-generator must install and maintain a manual disconnect switch that will disconnect the generating facility from the Company's distribution system. The disconnect switch must be a lockable, load-break switch that plainly indicates whether it is in the open or closed position. Except as provided in R746-312-4(2) (a) (ii), the disconnect switch must be readily accessible to the Company at all times and located within ten (10) feet of the Company's meter.
9. The Company shall not be liable directly or indirectly for permitting or continuing to allow an attachment of a net metering facility, or for the acts or omissions of the customer-generator that cause loss or injury, including death, to any third party.
10. The Company may test and inspect an interconnection at times that the electrical corporation considers necessary to ensure the safety of electrical workers and to preserve the integrity of the electric power grid.
11. Unless otherwise agreed to by a separate contract, the owner of the renewable energy facility retains ownership of the non-energy attributes associated with electricity the facility generates.

ELECTRIC SERVICE REGULATIONS: Service under this Schedule will be in accordance with the terms of the Electric Service Agreement between the Customer and the Company. The Electric Service Regulations of the Company on file with and approved by the Public Service Commission of the State of Utah, including future applicable amendments, will be considered as forming a part of and incorporated in said Agreement.