

ELECTRIC SERVICE SCHEDULE NO. 115 - Continued
Table 3a – HVAC Equipment Incentive Table – continued

Equipment Type	Size Category	Sub-Category	\$50/ton	\$75/ton	\$100/ton
Heat Pumps, Air-Cooled (Heating Mode) - See Note 3	< 65,000 Btu/hr (single phase)	Split system	8.5 HSPF	--	
		Single package	8.0 HSPF	--	
	< 65,000 Btu/hr (three phase)	Split system	--	8.5 HSPF	9.0 HSPF
		Single package	--	8.0 HSPF	8.5 HSPF
	≥ 65,000 Btu/hr and < 135,000 Btu/hr	47°F db/43°F wb outdoor air	--	3.4 COP	
		17°F db/15°F wb outdoor air	--	2.4 COP	
	≥ 135,000 Btu/hr	47°F db/43°F wb outdoor air	--	3.2 COP	
		17°F db/15°F wb outdoor air	--	2.1 COP	
Heat Pumps, Water-Source (Cooling Mode)	< 135,000 Btu/hr	86°F Entering Water	14.0 EER	--	
Heat Pumps, Water-Source (Heating Mode) - See Note 3	< 135,000 Btu/hr	68°F Entering Water	4.6 COP	--	

Notes for table 3a - HVAC equipment incentive table

- For retrofits of existing equipment, incentives are for one-for-one same size equipment replacements. Exception: PTHPs can replace electric resistive heating, which must be removed.
- Equipment that meets or exceeds the efficiency requirements listed for the equipment category in the above table may qualify for an incentive. Equipment must meet both listed efficiency requirements to qualify for incentives.
- Incentives for heat pumps are \$50-100 per ton of cooling capacity ONLY. No incentives are paid per ton of heating capacity. Heat Pumps must meet both the cooling mode and heating mode efficiency requirements to qualify for per ton cooling efficiency incentives.
- Equipment size categories and capacities are specified in terms of net cooling capacity at AHRI standard conditions as determined by AHRI Standard 210/240 for units <65,000 Btu/hr, AHRI Standard 340/360 for units ≥65,000 Btu/hr, and AHRI Standard 310/380 for PTAC and PTHP units.

AHRI = Air-Conditioning, Heating, and Refrigeration Institute

SEER = Seasonal Energy Efficiency Ratio

EER = Energy Efficiency Ratio

COP = Coefficient of Performance

HSPF = Heating Seasonal Performance Factor

IPLV = Integrated Part Load Value

PTHP = Package Terminal Heat Pump

PTAC = Package Terminal Air Conditioner

HVAC = Heating, Ventilation and Air Conditioning

IEER = Integrated Energy Efficiency Ratio

(Continued)